


ANNUNCIATOR MODEL 561B



8 Zones
Expanded
View

FEATURES:

- Simple, Highly Visual Display
 - One Touch Zone Control
 - Micro-Controller Based
- Fully Programmable with Free Software
- Monitor Closed, Open and Multi-State Circuits (High Security)
- Input to Output Mapping (Multiple Outputs per Zone)
- Interface with Standard Controls via Communication Bus
- Up to 32 Zones with more than 30 Options

SPECIFICATIONS

| | |
|-----------------|--|
| MOUNTING | Desk Top |
| SIZE | 11" x 4 3/4" x 8" |
| COLOR | White Powder Coated Steel Box with Stainless Steel Faceplate |
| POWER | Includes 12 VDC Power Supply Requires 110 VAC Input |
| INPUTS | Normally Closed, Normally Open or High Security Multi-State End-of-Line Resistor Loop (Color Coded) |
| OUTPUTS | One Open Collector Output per Zone Rated at 24 VDC, 100 mA (Color Coded) |
| OTHER | Four Auxiliary Control Inputs and 2 Common Zone Outputs may be programmed for a variety of functions |



Intrusion

Contacts, Motion Sensors, Panic Buttons, Cameras



Nurse Call

Panic Buttons, Fall Sensors, Cameras



Perimeter

Fence Vibration Sensors, Motion Sensors, Cameras



Flood

Water Sensors

Accessories from Flair:

- Magnetic Contacts
- Fence Vibration Sensors
- Water Sensors
- Pagers · Dialers
- Remote Graphic Displays

OPERATION:

Simple, Visual, Intuitive

Flair Multi-Zone Annunciators can be used as "stand alone" annunciators or network with other annunciators via communication module. Graphic Displays are also available. Each zone has a green LED for status, a red LED for alarm, a yellow LED for shunt and a zone control button for acknowledge, reset and bypass functions. Zone and common input and output type, timers and other features are programmable with easy to use free software.