

ANNUNCIATOR MODEL 531



FEATURES:

- Simple, Highly Visual Display
- One Touch Zone Control
- Micro-Controller Based
- Fully Programmable with Free Software
- Monitor Closed, Open and Multi-State Circuits (High Security)
- Input to Output Mapping (Multiple Outputs per Zone)
- 8 Zones with more than 30 Options

SPECIFICATIONS

MOUNTING	Recessed
SIZE	4 1/2" X 4 1/2" X 2"
COLOR	Stainless Steel Faceplate
POWER	Requires 12 VDC Power Supply
INPUTS	Normally Closed, Normally Open or High Security Multi-Sate End-of-Line Resistor Loop (Color Coded)
OUTPUTS	One Open Collector Output per zone rated at 24 VDC, 100 mA (Color Coded)
OTHER	Four Auxiliary Control Inputs and 2 Common Zone Outputs may be programmed for a variety of functions



Intrusion
Contacts, Motion Sensors, Panic Buttons, Cameras



Nurse Call
Panic Buttons, Fall Sensors, Cameras



Food Storage
Contacts, Temperature Sensors



Flood
Water Sensors

Accessories from Flair:

- Back Boxes
- Veneers
- Contacts
- Temperature Sensors
- Water Sensors



Wood Grain Veneer with Engraved Identification

OPERATION: **Simple yet Sophisticated**

Flair Multi-Zone Annunciators can be used as "stand alone" annunciators or interface with any other control panel via communication bus. Slave configurations are also available for all models. Each zone has a green LED for status, a red LED for alarm memory, a yellow LED for shunt and a zone control button for acknowledge, reset and bypass functions. Zone and common input and output type, timers and other features are programmable with easy to use free software.